



Customization of Footing Templates and Custom Abutments



Steve Willoughby
Senior Application Engineer, Bridges and Tunnels

© 2023 Bentley Systems, Incorporated

Bentley[®]

OBM Pier Column Definition

- Variable: Multiple cross sections, several fixed length, one adjustable length



OBM Variable Column Definition


- For each section :
 - Height
 - Shape
 - Start Dimension
 - End Dimension
 - Variation Type
 - Adjustable Height (Yes-No)
-
- Hint: Definition starts at the top of the column

Sections						
	Add Section	Delete Selected	Up	Down		
	Section Height (m)	Shape	Start Dimensions (mm) (W, L, X, Y)	End Dimensions (mm) (W, L, X, Y)	Variation	Adjustable Height
>	0.55000	Rect-Fillet	4165.60000, 1524.00000, 152.40000	3937.00000, 1524.00000, 152.40000	Parabolic Start	<input type="checkbox"/>
	1.90000	Rect-Fillet	3937.00000, 1524.00000, 152.40000	2438.40000, 1524.00000, 152.40000	Parabolic End	<input type="checkbox"/>
	9.55000	Template			Linear	<input checked="" type="checkbox"/>

OBM Variable Column Definition

- Column Section Height:

- Fixed section for all except one which adjustable height
- The section can have different dimensions at start and end
- If dimensions are different, the variation type can be chosen among:
- One and only shape per section
- Shapes among:



Adjustable Height	
Start Dimensions (mm) (W, L, X, Y)	End Dimensions (mm) (W, L, X, Y)
4165.60000, 1524.00000, 152.40000	3937.00000, 1524.00000, 152.40000



OBM Variable Column Definition

- Template:
 - Pick a template from library stored in Templates.xml
 - The template can be controlled by variables

Variables				0.00 - 9.55000 Florida\Base Rotation By Angle* Default = 0°							
Variable	Active	Default	Errors								
Rotation By Angle*	<input checked="" type="checkbox"/>	0°									
Rotation By Slope*	<input type="checkbox"/>	0.00000									
				Add Section	From Head	0.00000	m				
				Relative Location	Height	Start Value	End Value	Transition			
					0.00000	9.55000	5°	10	Linear		



OBM Custom Footing

- Template shape:
 - In utilities, open Footing library
 - We access a usual template editor




OBM Custom Footing

- Add a new template by drawing exterior definition of the footing
- Add Pile Locations by adding Circles




OBM Custom Footing


- Tag circles representing Pile locations



OBM Custom Footing

- Save the template
- Edit constraints and variables





Point Details Key Points

Points

Name	Type1	Type2	Variable1	Variable2
P_0	Angle	Offset		Left_WingWall_W...
P_1	Angle	Offset	Left_WingWall_Angle	Left_WingWall_Of...
P_2	Horizontal	Vertical	Horizontal_Offset	Vertical_Offset
P_3	Horizontal	Vertical	Length	
P_4	Angle	Offset	Right_WingWall_Angle	Right_WingWall_O...
P_5	Angle	Offset		Right_WingWall_O...
P_6	Offset	Offset	Width	Right_WingWall_W...
P_7	Offset	Offset	Left_WingWall_Width	Width

Edit Details

Name



Point Constraints

Mode

Angle + Offset

Constraint

Type Angle

Parent

Value

Variable

Ref To

Constraint

Offset

Corner Attributes

Mode

Rotation

Do Not Rotate


Save

Cancel

Close

OBM Custom Footing

- In the Pier or Abutment definition menu, choose Custom footing
- Modify Footing parameters
 - Height
 - Rotation Angle
 - Transverse and Longitudinal Offsets
- Adjust the Pile parameters
 - Pile Shape and Dimensions
 - Embed Length
 - Batter and Length of the Pile



Limitations

- Limited transfer to LBS/LBC assuming bounding box
- No transfer to RM at this time
- No transfer via dgn file. Need to Import/Export Template

